

Control Commands

**Model No. PT-VX505NU/NE/NEA,
PT-VW435NU/NE/NEA**

CONTENTS

1. BASIC FORMAT.....	4
2. BASIC CONTROL COMMAND.....	5
2.1. Power ON (LAMP ON)	5
2.2. Power OFF (STANDBY).....	5
2.3. VOLUME (+) Key	5
2.4. VOLUME (−) Key	5
2.5. INPUT SELECT.....	6
2.6. FREEZE Key.....	6
2.7. FREEZE Key (TOGGLE).....	6
2.8. MENU Key.....	6
2.9. ENTER Key.....	7
2.10. UP (↑) Key	7
2.11. DOWN (↓) Key.....	7
2.12. LEFT (←) Key	7
2.13. RIGHT (→) Key	7
2.14. AUTO SETUP Key	8
2.15. AV MUTE Key	8
2.16. AV MUTE Key (TOGGLE).....	8
2.17. D. ZOOM ▲ Key.....	8
2.18. D. ZOOM ▼ Key.....	8
2.19. KEYSTONE Key.....	9
2.20. PAGE UP Key.....	9
2.21. PAGE DOWN Key	9
2.22. PICTURE MODE.....	9
2.23. CONTRAST.....	9
2.24. BRIGHTNESS.....	10

2.25.	COLOR.....	10
2.26.	TINT.....	10
2.27.	SHARPNESS	11
2.28.	COLOR TEMPERATURE.....	11
2.29.	DAYLIGHT VIEW.....	11
2.30.	PROGRESSIVE	12
2.31.	NOISE REDUCTION.....	12
2.32.	TV SYSTEM	12
2.33.	RGB/YPbPr	12
2.34.	KEYSTONE.....	13
2.35.	SHIFT H.....	13
2.36.	SHIFT V.....	13
2.37.	DOT CLOCK	14
2.38.	FINE SYNC	14
2.39.	SCREEN	14
2.40.	LANGUAGE	15
2.41.	HDMI SETUP	15
2.42.	CLOSED CAPTION SETTING	15
2.43.	ASPECT (Only available for model VW435N series).....	16
2.44.	LOGO	16
2.45.	AUTO INPUT MODE SELECTION	16
2.46.	INPUT SEARCH.....	16
2.47.	BACKGROUND.....	17
2.48.	DIRECT ON.....	17
2.49.	INSTALLATION	17
2.50.	FAN CONTROL.....	17
2.51.	LAMP POWER	18
2.52.	POWER MANAGEMENT	18
2.53.	STANDBY MODE	18
2.54.	EMULATE MODE	18
2.55.	VOLUME	19
2.56.	MUTE	19
2.57.	WIRELESS LAN.....	20
2.58.	Query POWER	20
2.59.	Query INPUT SELECT	20
2.60.	Query FREEZE	21
2.61.	Query AV MUTE	21
2.62.	Query PICTURE MODE.....	21
2.63.	Query CONTRAST.....	22
2.64.	Query BRIGHTNESS	22
2.65.	Query COLOR.....	22
2.66.	Query TINT	22

2.67.	Query SHARPNESS	23
2.68.	Query COLOR TEMPERATURE.....	23
2.69.	Query DAYLIGHT VIEW.....	23
2.70.	Query PROGRESSIVE	24
2.71.	Query NOISE REDUCTION.....	24
2.72.	Query TV SYSTEM	24
2.73.	Query RGB/YPbPr	24
2.74.	Query KEYSTONE	25
2.75.	Query SHIFT H.....	25
2.76.	Query SHIFT V.....	25
2.77.	Query DOT CLOCK.....	26
2.78.	Query FINE SYNC	26
2.79.	Query SCREEN.....	26
2.80.	Query LANGUAGE.....	26
2.81.	Query HDMI SETUP	27
2.82.	Query CLOSED CAPTION SETTING	27
2.83.	Query ASPECT (Available only for model VW435N series)	28
2.84.	Query LOGO	28
2.85.	Query AUTO INPUT MODE SELECTION.....	28
2.86.	Query INPUT SEARCH.....	28
2.87.	Query BACKGROUND.....	29
2.88.	Query DIRECT ON	29
2.89.	Query INSTALLATION	29
2.90.	Query FAN CONTROL	29
2.91.	Query LAMP POWER	30
2.92.	Query POWER MANAGMENT	30
2.93.	Query STANDBY MODE	30
2.94.	Query EMULATE MODE	30
2.95.	Query VOLUME	31
2.96.	Query RUNTIME - LAMP	31
2.97.	Query LAMP STATUS	32
2.98.	Query TEMP INFORMATION.....	32
2.99.	Query SERIAL NUMBER	32
2.100.	Query MAC ADDRESS	32
2.101.	Query RUNTIME - PROJECTOR.....	33
2.102.	Query LAMP SERIAL NUMBER	33

1. BASIC FORMAT

Transmission from the computer begins with STX, and then the command, parameter and ETX are set in order.
Add parameters according to the details of control.

Basic control command (without parameter)

Start (STX)	Command	End (ETX)
1 byte	3 bytes	1 byte

Basic control command (with parameter)

Start (STX)	Command	Separator (Colon)	Parameters Undefined	End (ETX)
1 byte	3 bytes	1 byte	length	1 byte

Response (Callback) of the basic control command

In the period when the command can be accepted

Differs according to each command

In the period when the command cannot be accepted or not available.

Hexadecimal	02h	45h	52h	34h	30h	31h	03h
Character		E	R	4	0	1	

In case of the parameter error

Hexadecimal	02h	45h	52h	34h	30h	32h	03h
Character		E	R	4	0	2	

Attention:

- When sending several commands, be sure to wait for a response from the projector, and send the next command after 0.5 seconds or more pass.
- It might take time by the time the response returns because the command is processed in the projector.
Set the time-out to 10 seconds or longer

2. BASIC CONTROL COMMAND

Explanatory notes

○: Enable

✗ : Disable

2.1. Power ON (LAMP ON)

Hexadecimal	02h	50h	4Fh	4Eh	03h
Character	P	O	N		

■ Response (Callback)

In the period when the command can be accepted (This command in power-on condition is included.)

Hexadecimal	02h	50h	4Fh	4Eh	03h
Character	P	O	N		

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
✗	○	○	✗	✗	✗

■ Note:

- When you confirm whether to have succeeded in power-on, confirm it by QPW (Query Power) command after receiving the callback of PON command.

2.2. Power OFF (STANDBY)

Hexadecimal	02h	50h	4Fh	46h	03h
Character	P	O	N	F	

■ Response (Callback)

In the period when the command can be accepted (This command in power-on condition is included.)

Hexadecimal	02h	50h	4Fh	46h	03h
Character	P	O	N	F	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	✗	✗	○	○	○

■ Note:

- When you confirm whether to have succeeded in power-off, confirm it by QPW (Query Power) command after receiving the callback of PON command.

2.3. VOLUME (+) Key

Hexadecimal	02h	41h	55h	55h	03h
Character	A	U	U	U	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	41h	55h	55h	03h
Character	A	U	U	U	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
✗	✗	✗	○	○	○

2.4. VOLUME (-) Key

Hexadecimal	02h	41h	55h	44h	03h
Character	A	U	U	D	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	41h	55h	44h	03h
Character	A	U	U	D	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
✗	✗	✗	○	○	○

2.5. INPUT SELECT

Hexadecimal Character	02h I	49h I	49h S	53h :	3Ah :	*1 *2	*3 *4	*5 *6	03h
--------------------------	----------	----------	----------	----------	----------	----------	----------	----------	-----

■ Parameters (*1,*2,*3,*4,*5,*6)

	COMPUTER1			COMPUTER2		
Hexadecimal Character	52h R	47h G	31h 1	52h R	47h G	32h 2
	VIDEO			S-VIDEO		
Hexadecimal Character	56h V	49h I	44h D	53h S	56h V	44h D
	SCART			HDMI		
Hexadecimal Character	53h S	43h C	54h T	48h H	44h D	31h 1

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h I	49h I	49h S	53h :	3Ah :	*1 *2	*3 *4	*5 *6	03h
--------------------------	----------	----------	----------	----------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■ Note:

- When the "Monitor out" is selected for COMPUTER2 with the terminal setting and then COMPUTER2 is selected, ER401 is returned.

2.6. FREEZE Key

Hexadecimal Character	02h O	4Fh F	46h Z	5Ah :	3Ah :	*1 *2	03h
--------------------------	----------	----------	----------	----------	----------	----------	-----

■ Parameters (*1,*2)

	OFF	ON
Hexadecimal Character	30h 0	31h 1

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh F	46h Z	5Ah :	3Ah :	*1 *2	03h
--------------------------	----------	----------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

2.7. FREEZE Key (TOGGLE)

Hexadecimal Character	02h O	4Fh F	46h Z	5Ah :	03h
--------------------------	----------	----------	----------	----------	-----

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh F	46h Z	5Ah :	03h
--------------------------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

2.8. MENU Key

Hexadecimal Character	02h O	4Fh M	4Dh N	4Eh :	03h
--------------------------	----------	----------	----------	----------	-----

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh M	4Dh N	4Eh :	03h
--------------------------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.9. ENTER Key

Hexadecimal Character	02h O	4Fh E	45h N	4Eh N	03h
--------------------------	----------	----------	----------	----------	-----

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh E	45h N	4Eh N	03h
--------------------------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	×	×	○	○	○

2.10. UP (↑) Key

Hexadecimal Character	02h O	4Fh C	43h U	55h U	03h
--------------------------	----------	----------	----------	----------	-----

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh C	43h U	55h U	03h
--------------------------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	×	×	○	○	○

2.11. DOWN (↓) Key

Hexadecimal Character	02h O	4Fh C	43h D	44h D	03h
--------------------------	----------	----------	----------	----------	-----

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh C	43h D	44h D	03h
--------------------------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	×	×	○	○	○

2.12. LEFT (←) Key

Hexadecimal Character	02h O	4Fh C	43h L	4Ch L	03h
--------------------------	----------	----------	----------	----------	-----

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh C	43h L	4Ch L	03h
--------------------------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	×	×	○	○	○

2.13. RIGHT (→) Key

Hexadecimal Character	02h O	4Fh C	43h R	52h R	03h
--------------------------	----------	----------	----------	----------	-----

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh C	43h R	52h R	03h
--------------------------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	×	×	○	○	○

2.14. AUTO SETUP Key

Hexadecimal Character	02h O	4Fh A	41h S	53h S	03h
--------------------------	----------	----------	----------	----------	-----

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh A	41h S	53h S	03h
--------------------------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.15. AV MUTE Key

Hexadecimal Character	02h O	4Fh S	53h H	48h H	3Ah :	*1 *2	03h
--------------------------	----------	----------	----------	----------	----------	----------	-----

■ Parameters (*1,*2)

Hexadecimal Character	AV MUTE OFF 0	AV MUTE ON 1
Hexadecimal Character	30h	31h

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh S	53h H	48h H	3Ah :	*1 *2	03h
--------------------------	----------	----------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.16. AV MUTE Key (TOGGLE)

Hexadecimal Character	02h O	4Fh S	53h H	48h H	03h
--------------------------	----------	----------	----------	----------	-----

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh S	53h H	48h H	03h
--------------------------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.17. D. ZOOM ▲ Key

Hexadecimal Character	02h D	44h Z	5Ah U	55h U	03h
--------------------------	----------	----------	----------	----------	-----

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h D	44h Z	5Ah U	55h U	03h
--------------------------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

2.18. D. ZOOM ▼ Key

Hexadecimal Character	02h D	44h Z	5Ah D	44h D	03h
--------------------------	----------	----------	----------	----------	-----

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h D	44h Z	5Ah D	44h D	03h
--------------------------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

2.19. KEYSTONE Key

Hexadecimal Character	02h	4Bh	53h	54h	03h
	K	S	T		

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Bh	53h	54h	03h
	K	S	T		

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.20. PAGE UP Key

Hexadecimal Character	02h	4Fh	55h	50h	03h
	O	U	U	P	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Fh	55h	50h	03h
	U	U	P		

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

2.21. PAGE DOWN Key

Hexadecimal Character	02h	4Fh	44h	50h	03h
	O	D	D	P	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Fh	44h	50h	03h
	O	D	D	P	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

2.22. PICTURE MODE

Hexadecimal Character	02h	56h	50h	4Dh	3Ah	*1	*3	*5	03h
	V	P	M	M	:	*2	*4	*6	

■Parameters (*1,*2,*3,*4,*5,*6)

DYNAMIC			STANDARD			CINEMA			
Hexadecimal Character	44h	59h	4Eh	53h	54h	44h	43h	49h	4Eh
	D	Y	N	S	T	D	C	I	N
REAL			BLACK BOARD			COLOR BOARD			
Hexadecimal Character	52h	45h	41h	42h	42h	44h	43h	42h	44h
	R	E	A	B	B	D	C	B	D
IMAGE 1			IMAGE 2			IMAGE 3			
Hexadecimal Character	49h	4Dh	31h	49h	4Dh	32h	49h	4Dh	33h
	I	M	1	I	M	2	I	M	3
IMAGE 4									
Hexadecimal Character	49h	4Dh	34h						
	I	M	4						

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	50h	4Dh	3Ah	*1	*3	*5	03h
	V	P	M	M	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.23. CONTRAST

Hexadecimal Character	02h	56h	43h	4Eh	3Ah	*1	*3	*5	03h
	V	P	C	N	:	*2	*4	*6	

■Parameters (*1,*2,*3,*4,*5,*6)

Hexadecimal	0	1	2
	30h	30h	30h

Character	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal Character	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	43h	4Eh	3Ah	*1	*3	*5	03h
Character	V	C	N	:	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.24. BRIGHTNESS

Hexadecimal Character	02h	56h	42h	52h	3Ah	*1	*3	*5	03h
Character	V	B	R	:	:	*2	*4	*6	

■Parameters (*1,*2,*3,*4,*5,*6)

Hexadecimal Character	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal Character	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	42h	52h	3Ah	*1	*3	*5	03h
Character	V	B	R	:	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.25. COLOR

Hexadecimal Character	02h	56h	43h	4Fh	3Ah	*1	*3	*5	03h
Character	V	C	O	:	:	*2	*4	*6	

■Parameters (*1,*2,*3,*4,*5,*6)

Hexadecimal Character	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal Character	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	43h	4Fh	3Ah	*1	*3	*5	03h
Character	V	C	O	:	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.26. TINT

Hexadecimal Character	02h	56h	54h	4Eh	3Ah	*1	*3	*5	03h
Character	V	T	N	:	:	*2	*4	*6	

■Parameters (*1,*2,*3,*4,*5,*6)

Hexadecimal Character	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal Character	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	54h	4Eh	3Ah	*1	*3	*5	03h
Character	V	T	N	:	:	*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.27. SHARPNESS

Hexadecimal Character	02h	56h	53h	52h	3Ah	*1 *2	*3 *4	*5 *6	03h
-----------------------	-----	-----	-----	-----	-----	----------	----------	----------	-----

■ Parameters (*1,*2,*3,*4,*5,*6)

Hexadecimal Character	0			1			2		
	30h 0	30h 0	30h 0	30h 0	30h 0	31h 1	30h 0	30h 0	32h 2
Hexadecimal Character	13			14			15		
	30h 0	31h 1	33h 3	30h 0	31h 1	34h 4	30h 0	31h 1	35h 5

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	53h	52h	3Ah	*1 *2	*3 *4	*5 *6	03h
-----------------------	-----	-----	-----	-----	-----	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.28. COLOR TEMPERATURE

[LOW/MID/HIGH]

Hexadecimal Character	02h	4Fh	54h	45h	3Ah	*1 *2	03h
-----------------------	-----	-----	-----	-----	-----	----------	-----

■ Parameters (*1,*2)

	LOW	MID	HIGH
Hexadecimal Character	30h 0	31h 1	32h 2

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Fh	54h	45h	3Ah	*1 *2	03h
-----------------------	-----	-----	-----	-----	-----	----------	-----

[XLOW]

Hexadecimal Character	02h	4Fh	54h	45h	3Ah	*1 *2	*3 *4	03h
-----------------------	-----	-----	-----	-----	-----	----------	----------	-----

■ Parameters (*1,*2,*3,*4)

	XLOW	
Hexadecimal Character	31h 1	31h 1

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Fh	54h	45h	3Ah	*1 *2	*3 *4	03h
-----------------------	-----	-----	-----	-----	-----	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.29. DAYLIGHT VIEW

Hexadecimal Character	02h	56h	58h	58h	3Ah	44h	4Ch	56h	49h
Hexadecimal Character	30h	3Dh	2Bh	*1 + *2	: *3 *4	D *5 *6	L *7 *8	V *9 *1-	03h

■ Parameters (*1,*2,*3,*4,*5,*6,*7,*8,*9,*10)

In case of Front Installation

Hexadecimal Character	OFF				
	30h 0	30h 0	30h 0	30h 0	30h 0
AUTO					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	31h 1
ON					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	32h 2

In case of Rear Installation

Hexadecimal Character	OFF				
	30h	30h	30h	30h	30h

Character	0	0	0	0	0		
ON							
Character	30h	30h	30h	30h	31h		
Character	0	0	0	0	1		

2.30. PROGRESSIVE

Hexadecimal Character	02h	4Fh	50h	44h	3Ah	*1	03h
-----------------------	-----	-----	-----	-----	-----	----	-----

■ Parameters (*1,*2)

	FILM	OFF	L1
Hexadecimal Character	30h	31h	32h
Character	0	1	2

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	4Fh	50h	44h	3Ah	*1	03h
-----------------------	-----	-----	-----	-----	-----	----	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■ Note:

- This command is available only when an interlaced signal is inputted. In other cases, ER401 is returned.

2.31. NOISE REDUCTION

Hexadecimal Character	02h	56h	4Eh	52h	3Ah	*1	03h
-----------------------	-----	-----	-----	-----	-----	----	-----

■ Parameters (*1,*2)

	OFF	L1	L2
Hexadecimal Character	30h	31h	32h
Character	0	1	2

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	4Eh	52h	3Ah	*1	03h
-----------------------	-----	-----	-----	-----	-----	----	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.32. TV SYSTEM

Hexadecimal Character	02h	56h	53h	47h	3Ah	*1	*3	*5	03h
-----------------------	-----	-----	-----	-----	-----	----	----	----	-----

■ Parameters (*1,*2,*3,*4,*5,*6)

	AUTO			NTSC			NTSC4.43			PAL		
Hexadecimal Character	41h	55h	54h	4Eh	54h	53h	4Eh	34h	34h	50h	41h	4Ch
	A	U	T	N	T	S	N	4	4	P	A	L
	PAL-M			PAL-N			SECAM					
Hexadecimal Character	50h	41h	4Dh	50h	41h	4Eh	53h	45h	43h			
Character	P	A	M	P	A	N	S	E	C			

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h	56h	53h	47h	3Ah	*1	*3	*5	03h
-----------------------	-----	-----	-----	-----	-----	----	----	----	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■ Note:

- This command is acceptable only when the input is VIDEO or S-VIDEO. In other cases, ER401 is returned.

2.33. RGB/YPbPr

Hexadecimal Character	02h	4Fh	52h	46h	3Ah	*1	03h
-----------------------	-----	-----	-----	-----	-----	----	-----

■ Parameters (*1,*2)

	YPbPr
Hexadecimal Character	31h

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh R	52h F	46h :	*1 *2	03h
-----------------------	----------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■ Note:

- This command is acceptable only when the input is Computer 1-RGB or Computer 1-component.

2.34. KEYSTONE

Hexadecimal Character	02h O	4Fh K	4Bh S	53h :	*1 *2	*3 *4	*5 *6	03h
-----------------------	----------	----------	----------	----------	----------	----------	----------	-----

■ Parameters (*1,*2,*3,*4,*5,*6)

-60			-59			-58		
Hexadecimal Character	2Dh —	36h 6	30h 0	2Dh —	35h 5	39h 9	2Dh —	35h 5
58			59			60		
Hexadecimal Character	30h 0	35h 5	38h 8	30h 0	35h 5	39h 9	30h 0	36h 6

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh K	4Bh S	53h :	3Ah *1	*1 *2	*3 *4	*5 *6	03h
-----------------------	----------	----------	----------	----------	-----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.35. SHIFT H

Hexadecimal Character	02h V	56h H	48h P	50h :	3Ah *1	*1 *2	*3 *4	*5 *6	*7 *8	03h
-----------------------	----------	----------	----------	----------	-----------	----------	----------	----------	----------	-----

■ Parameters (*1,*2,*3,*4,*5,*6,*7,*8)

0				1				
Hexadecimal Character	30h 0	30h 0	03h 0	30h 0	30h 0	30h 0	31h 1	
319				320				
Hexadecimal Character	30h 0	33h 3	31h 1	39h 9	30h 0	33h 3	32h 20	30h 0

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h V	56h H	48h P	50h :	3Ah *1	*1 *2	*3 *4	*5 *6	*7 *8	03h
-----------------------	----------	----------	----------	----------	-----------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

■ Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.
- The parameter differs according to the input signals.

2.36. SHIFT V

Hexadecimal Character	02h V	56h V	56h P	50h :	3Ah *1	*1 *2	*3 *4	*5 *6	03h
-----------------------	----------	----------	----------	----------	-----------	----------	----------	----------	-----

■ Parameters (*1,*2,*3,*4,*5,*6)

0			1			2		
Hexadecimal Character	30h 0	3-h 0	30h 0	30h 0	30h 0	31h 1	30h 0	30h 0
36			37			38		
Hexadecimal Character	30h 0	33h 3	36h 6	30h 0	33h 3	37h 7	30h 0	33h 3

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h V	56h V	56h P	50h :	3Ah *1	*1 *2	*3 *4	*5 *6	03h
-----------------------	----------	----------	----------	----------	-----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

■ Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.
- The parameter differs according to the input signals.

2.37. DOT CLOCK

Hexadecimal Character	02h V	56h D	44h C	43h :	3Ah :	*1 *2	*3 *4	*5 *6	03h
--------------------------	----------	----------	----------	----------	----------	----------	----------	----------	-----

■ Parameters (*1,*2,*3,*4,*5,*6,*7,*8)

Hexadecimal Character	1190				1189			
	31h 1	31h 1	39h 9	30h 0	31h 1	31h 1	38h 8	39h 9
Hexadecimal Character	2894				2895			
	32h 2	38h 8	39h 9	34h 4	32h 2	38h 8	39h 9	35h 5

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h V	56h D	44h C	43h :	3Ah :	*1 *2	*3 *4	*5 *6	03h
--------------------------	----------	----------	----------	----------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

■ Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.
- The parameter differs according to the input signals.

2.38. FINE SYNC

Hexadecimal Character	02h V	56h D	43h C	50h P	3Ah :	*1 *2	*3 *4	*5 *6	03h
--------------------------	----------	----------	----------	----------	----------	----------	----------	----------	-----

■ Parameters (*1,*2,*3,*4,*5,*6)

Hexadecimal Character	0			1			2		
	30h 0	30h 0	30h 0	30h 0	30h 0	31h 1	30h 0	30h 0	32h 2
Hexadecimal Character	29			30			31		
	30h 0	32h 2	39h 9	30h 0	33h 3	30h 0	30h 0	33h 3	31h 1

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h V	56h D	43h C	50h P	3Ah :	*1 *2	*3 *4	*5 *6	03h
--------------------------	----------	----------	----------	----------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

■ Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.

2.39. SCREEN

Hexadecimal Character	02h V	56h S	53h 1	31h :	3Ah :	*1 *2	*3 *4	03h
--------------------------	----------	----------	----------	----------	----------	----------	----------	-----

■ Parameters (*1,*2,*3,*4)

Hexadecimal Character	NORMAL		WIDE		TRUE		FULL		ZOOM
	30h 0	31h 1	30h 0	32h 2	30h 0	35h 5	30h 0	36h 6	34h 4
Hexadecimal Character	PITTARI-WIDE				CUSTOM				ZOOM
	36h 6	30h 0	35h 5	30h 0					

* PITTARI-WIDE is only available for model VW435N series.

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h V	56h S	53h 1	31h :	3Ah :	*1 *2	*3 *4	03h
--------------------------	----------	----------	----------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■ Note:

- When unselective mode is selected at the no signal, ER401 is returned.

2.40. LANGUAGE

Hexadecimal Character	02h O	4Fh L	4Ch G	47h :	3Ah :	*1 *2	*3 *4	*5 *6	03h
-----------------------	----------	----------	----------	----------	----------	----------	----------	----------	-----

■ Parameters (*1,*2,*3,*4,*5,*6,)

	English			German			French		
Hexadecimal Character	45h E	4Eh N	47h G	44h D	45h E	55h U	46h F	52h R	41h A
	Spanish			Italian			Japanese		
Hexadecimal Character	45h E	53h S	50h P	49h I	54h T	4Ch L	4Ah J	50h P	4Eh N
	Chinese			Russian			Korean		
Hexadecimal Character	43h C	48h H	49h I	52h R	55h U	53h S	4Bh K	4Fh O	52h R
	Portuguese			Swedish			Norwegian		
Hexadecimal Character	50h P	4Fh O	52h R	53h S	56h V	45h E	4Eh N	4Fh O	52h R
	Danish			Polish			Czech		
Hexadecimal Character	44h D	41h A	4Eh N	50h P	4Fh O	4Ch L	43h C	45h E	53h S
	Hungarian			Thai			Holland		
Hexadecimal Character	4Dh M	41h A	47h G	54h T	48h H	41h A	4Eh N	4Ch L	44h D
	Finland			Romanian			Turkish		
Hexadecimal Character	46h F	49h I	4Eh N	52h R	55h U	4Dh M	54h T	55h Ü	52h R
	Arabic			kazakhstan			Vietnamese		
Hexadecimal Character	41h A	52h R	41h A	4Bh K	41h A	5Ah Z	56h V	49h I	45h E

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h O	4Fh L	4Ch G	47h :	3Ah :	*1 *2	*3 *4	*5 *6	03h
-----------------------	----------	----------	----------	----------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.41. HDMI SETUP

Hexadecimal Character	02h V	56h X	58h X	58h X	3Ah :	48h H	53h S	4Ch L	49h I
Hexadecimal Character	30h 0	3Dh =	2Bh +	*1 *2	*3 *4	*5 *6	*7 *8	*9 *10	03h

■ Parameters (*1,*2,*3,*4,*5,*6,*7,*8,*9,*10)

	EXPAND				
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	30h 0
NORMAL					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	31h 1

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h V	56h X	58h X	58h X	3Ah :	48h H	53h S	4Ch L	49h I
Hexadecimal Character	30h 0	3Dh =	2Bh +	*1 *2	*3 *4	*5 *6	*7 *8	*9 *10	03h

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.42. CLOSED CAPTION SETTING

Hexadecimal Character	02h O	4Fh C	43h C	43h C	3Ah :	*1 *2	03h
-----------------------	----------	----------	----------	----------	----------	----------	-----

■ Parameters (*1,*2)

	OFF	CC1	CC2	CC3	CC4
Hexadecimal Character	30h 0	31h 1	32h 2	33h 3	34h 4

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	43h	43h	3Ah	*1 *2	03h
Character	O	C	C	:			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	x	o	o

■Note:

- This command is effective only when the system is fixed with "NTSC" and the proper signals (NTSC Video or S-Video signal) are input.

2.43. ASPECT (Only available for model VW435N series)

Hexadecimal	02h	56h	53h	46h	3Ah	*1 *2	03h
Character	V	S	F	:			

■Parameters (*1,*2)

	16:10	16:9	4:3
Hexadecimal	30h	31h	32h

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	53h	46h	3Ah	*1 *2	03h
Character	V	S	F	:			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.44. LOGO

Hexadecimal	02h	4Dh	4Ch	4Fh	3Ah	*1 *2	03h
Character	M	L	O	:			

■Parameters (*1,*2)

	OFF	USER	DEFAULT
Hexadecimal	30h	31h	32h

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Dh	4Ch	4Fh	3Ah	*1 *2	03h
Character	M	L	O	:			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■Note:

- When the Logo PIN code is "ON", ER401 is returned.
- When the user registered Logo is not available, "OFF" and "DEFAULT" are effectice. In other cases, ER401 is returned.

2.45. AUTO INPUT MODE SELECTION

Hexadecimal	02h	4Fh	53h	53h	3Ah	*1 *2	03h
Character	O	S	S	:			

■Parameters (*1,*2)

	ON1	ON2
Hexadecimal	30h	31h

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	53h	53h	3Ah	*1 *2	03h
Character	O	S	S	:			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■Note:

- This command is effevtive only when the Signal Search selects "ON2". In other cases, ER401 is returned.

2.46. INPUT SEARCH

Hexadecimal	02h	4Fh	53h	52h	3Ah	*1 *2	03h
Character	O	S	R	:			

■Parameters (*1,*2)

	OFF	ON2
--	-----	-----

Hexadecimal	30h	31h
Character	0	1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	53h	52h	3Ah	*1	03h
Character	O	S	R	:	*	2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.47. BACKGROUND

Hexadecimal	02h	4Fh	42h	43h	3Ah	*1	03h
Character	O	B	C	:	*	2	

■Parameters (*1,*2)

	BLUE	BLACK	USER
Hexadecimal	30h	31h	32h
Character	0	1	2

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	42h	43h	3Ah	*1	03h
Character	O	B	C	:	*	2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■Note:

- When the user registered Logo is not available, "BLUE" and "BLACK" are effective. In other cases, ER401 is returned.

2.48. DIRECT ON

Hexadecimal	02h	4Fh	50h	59h	3Ah	*1	03h
Character	O	P	Y	:	*	2	

■Parameters (*1,*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	50h	59h	3Ah	*1	03h
Character	O	P	Y	:	*	2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.49. INSTALLATION

Hexadecimal	02h	4Fh	49h	4Ch	3Ah	*1	03h
Character	O	I	L	:	*	2	

■Parameters (*1,*2)

	FRONT/DESK	REAR/DESK	FRONT / CEILING	REAR/CEILING
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	49h	4Ch	3Ah	*1	03h
Character	O	I	L	:	*	2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.50. FAN CONTROL

Hexadecimal	02h	4Fh	46h	4Dh	3Ah	*1	03h
Character	O	F	M	:	*	2	

■Parameters (*1,*2)

	OFF	ON1
Hexadecimal	30h	31h
Character	0	1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	46h	4Dh	3Ah	*1	03h
Character	O	F	M	:	S	*2	I

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.51. LAMP POWER

Hexadecimal	02h	4Fh	4Ch	50h	3Ah	*1	03h
Character	O	F	L	P	:	*2	I

■Parameters (*1,*2)

	ECO	NORMAL
Hexadecimal	30h	31h
Character	0	1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Ch	50h	3Ah	*1	03h
Character	O	F	L	P	:	*2	I

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.52. POWER MANAGEMENT

Hexadecimal	02h	4Fh	41h	46h	3Ah	*1	*3	03h
Character	O	F	A	F	:	*2	*4	I

■Parameters (*1,*2,*3,*4)

	OFF	15	30
Hexadecimal	30h	30h	31h
Character	0	0	1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	41h	46h	3Ah	*1	*3	03h
Character	O	F	A	F	:	*2	*4	I

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

■Note:

- When setting "01" to "30", the setting of Power Management is set "Shut down" forcibly..

2.53. STANDBY MODE

Hexadecimal	02h	56h	58h	58h	3Ah	53h	54h	4Dh	49h
Character	V	X	X	:	S	T	M	I	
Hexadecimal	30h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
Character	0	=	+	*2	*4	*6	*8	*10	I

■Parameters (*1,*2,*3,*4,*5,*6,*7,*8,*9,*10)

	NORMAL				
Hexadecimal	30h	30h	30h	30h	30h
Character	0	0	0	0	0
	ECO				
Hexadecimal	30h	30h	30h	30h	33h
Character	0	0	0	0	3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	56h	58h	58h	3Ah	53h	54h	4Dh	49h
Character	V	X	X	X	:	S	T	M	I
Hexadecimal	30h	3Dh	2Bh	*1	*3	*5	*7	*9	03h
Character	0	=	+	*2	*4	*6	*8	*10	I

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.54. EMULATE MODE

Hexadecimal	02h	56h	58h	58h	3Ah	45h	4Dh	55h	49h
Character	V	X	X	X	:	E	M	U	I

Hexadecimal Character	30h 0	3Dh =	2Bh +	*1 *2	*3 *4	*5 *6	*7 *8	*9 *10	03h
-----------------------	----------	----------	----------	----------	----------	----------	----------	-----------	-----

■Parameters (*1, *2, *3, *4, *5, *6, *7, *8, *9, *10)

DEFAULT					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	31h 1
D3500					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	32h 2
D4000					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	33h 3
D/W5k series					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	34h 4
D/W/Z6k series					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	35h 5
L730					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	36h 6
L780					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	37h 7
L735					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	38h 8
L785					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	39h 9
LB/W series					
Hexadecimal Character	30h 0	30h 0	30h 0	31h 1	30h 0
F/W series					
Hexadecimal Character	30h 0	30h 0	30h 0	31h 1	31h 1

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h 0	56h V	58h X	58h X	3Ah :	45h E	4Dh M	55h U	49h I
Hexadecimal Character	30h 0	3Dh =	2Bh +	*1 *2	*3 *4	*5 *6	*7 *8	*9 *10	03h

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.55. VOLUME

Hexadecimal Character	02h A	41h V	56h L	4Ch :	3Ah :	*1 *2	*3 *4	*5 *6	03h
-----------------------	----------	----------	----------	----------	----------	----------	----------	----------	-----

■Parameters (*1, *2, *3, *4, *5, *6)

Hexadecimal Character	0			1			2		
	30h 0	30h 0	30h 0	30h 0	30h 0	31h 1	30h 0	30h 0	32h 2
61									
Hexadecimal Character	30h 0	36h 6	31h 1	30h 0	36h 6	32h 2	30h 0	36h 6	33h 3

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h A	41h V	56h L	4Ch :	3Ah :	*1 *2	*3 *4	*5 *6	03h
-----------------------	----------	----------	----------	----------	----------	----------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.56. MUTE

Hexadecimal Character	02h A	41h M	4Dh T	54h :	3Ah :	*1 *2	03h
-----------------------	----------	----------	----------	----------	----------	----------	-----

■ Parameters (*1,*2)

	Off	On
Hexadecimal	30h	31h
Character	0	1

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	41h	40h	54h	3Ah	*1	03h
Character	O	A	M	T	:	*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.57. WIRELESS LAN

Hexadecimal	02h	4Fh	4Eh	53h	3Ah	*1	03h
Character	O	N	S	:	*2		

■ Parameters (*1,*2)

OFF	1	2	3	4
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3
USER1	USER2	USER3	USER4	S-DIRECT
Hexadecimal	35h	36h	37h	38h
Character	5	6	7	8
M-DIRECT				
Hexadecimal	31h	30h		
Character	1	0		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	4Fh	4Eh	53h	3Ah	*1	03h
Character	O	N	S	:	*2		

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
x	x	x	o	o	o

2.58. Query POWER

Hexadecimal	02h	51h	50h	57h	03h
Character	Q	P	W	:	

■ Response (Callback)

OFF

Hexadecimal	02h	30h	30h	30h	03h
Character	0	0	0		

ON

Hexadecimal	02h	30h	30h	31h	03h
Character	0	0	1		

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
o	o	o	o	o	o

2.59. Query INPUT SELECT

Hexadecimal	02h	51h	49h	4Eh	03h
Character	Q	I	N	:	

■ Response (Callback)

COMPUTER1

Hexadecimal	02h	52h	47h	31h	03h
Character	R	G	1		

COMPUTER2

Hexadecimal	02h	52h	47h	32h	03h
Character	R	G	2		

VIDEO

Hexadecimal	02h	56h	49h	44h	03h
Character	V	I	D		

S-VIDEO

Hexadecimal	02h	53h	56h	44h	03h
Character	S	V	D		

COMPONENT

Hexadecimal	02h	52h	47h	31h	03h
Character	R	G	1		

SCART

Hexadecimal	02h	53h	43h	54h	03h
Character	S	C	T		

HDMI

Hexadecimal	02h	48h	44h	31h	03h
Character	H	D		1	

NETWORK

Hexadecimal	02h	4Eh	57h	50h	03h
Character	N	W	P		

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

2.60. Query FREEZE

Hexadecimal	02h	51h	46h	5Ah	03h
Character	Q	F	Z		

■Response (Callback)

OFF

Hexadecimal	02h	30h	03h
Character		0	

ON

Hexadecimal	02h	31h	03h
Character		1	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

2.61. Query AV MUTE

Hexadecimal	02h	51h	53h	48h	03h
Character	Q	S		H	

■Response (Callback)

OFF

Hexadecimal	02h	30h	03h
Character		0	

ON

Hexadecimal	02h	31h	03h
Character		1	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

2.62. Query PICTURE MODE

Hexadecimal	02h	51h	50h	4Dh	03h
Character	Q	P	M		

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

■Parameters (*1,*2,*3,*4,*5,*6)

Hexadecimal	STANDARD			DYNAMIC			CINEMA		
	S	T	D	D	Y	N	C	I	N
Hexadecimal	REAL			BLACK BOARD			COLOR BOARD		
	R	E	A	B	B	D	C	B	D
Hexadecimal	IMAGE 1			IMAGE 2			IMAGE 3		
	I	M	1	I	M	2	I	M	3
Hexadecimal	IMAGE 4								
	I	M	4						

2.63. Query CONTRAST

Hexadecimal	02h	51h	56h	52h	03h
Character	Q	V	R		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2,*3,*4,*5,*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

2.64. Query BRIGHTNESS

Hexadecimal	02h	51h	56h	42h	03h
Character	Q	V	R	B	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2,*3,*4,*5,*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

2.65. Query COLOR

Hexadecimal	02h	51h	56h	43h	03h
Character	Q	V	R	C	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2,*3,*4,*5,*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

2.66. Query TINT

Hexadecimal	02h	51h	56h	54h	03h
Character	Q	V	R	T	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (*1,*2,*3,*4,*5,*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

2.67. Query SHARPNESS

Hexadecimal	02h	51h	56h	53h	03h
Character	Q	V	S		

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (*1,*2,*3,*4,*5,*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	13			14			15		
Hexadecimal	30h	31h	33h	30h	31h	34h	30h	31h	35h
Character	0	1	3	0	1	4	0	1	5

2.68. Query COLOR TEMPERATURE

Hexadecimal	02h	51h	54h	45h	03h
Character	Q	V	E		

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (*1,*2)

	XLOW		LOW	MID	HIGH
Hexadecimal	31h	31h	30h	31h	32h
Character	1	1	0	1	2

2.69. Query DAYLIGHT VIEW

Hexadecimal	02h	51h	56h	58h	3Ah	44h	4Ch	56h	49h	30h	03h
Character	Q	V	X	:	:	D	L	V	I	0	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	44h	4Ch	56h	49h	30h	3Dh	2Bh
Character	D	L	V	I	0	=	+	
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (*1,*2,*3,*4,*5,*6, *7, *8, *9, *10)

In case of Front Installation

	OFF				
Hexadecimal	30h	30h	30h	30h	30h
Character	0	0	0	0	0
AUTO					
Hexadecimal	30h	30h	30h	30h	31h
Character	0	0	0	0	1
ON					
Hexadecimal	30h	30h	30h	30h	32h
Character	0	0	0	0	2

In case of Rear Installation

	OFF				

Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	30h 0
ON					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	31h 1

2.70. Query PROGRESSIVE

Hexadecimal Character	02h Q	51h P	50h D	44h 03h
-----------------------	----------	----------	----------	------------

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h *1 *2	03h
-----------------------	-----------------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2)

	FILM	OFF	ON
Hexadecimal Character	30h 0	31h 1	32h 2

■ Note:

- This command is available only when an interlaced signal is inputted. In other cases, ER401 is returned.

2.71. Query NOISE REDUCTION

Hexadecimal Character	02h Q	51h N	4Eh R	52h 03h
-----------------------	----------	----------	----------	------------

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h *1 *2	03h
-----------------------	-----------------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2)

	OFF	L1	L2
Hexadecimal Character	30h 0	31h 1	32h 2

2.72. Query TV SYSTEM

Hexadecimal Character	02h Q	51h S	53h G	47h 03h
-----------------------	----------	----------	----------	------------

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h *1 *2	*3 *4	*5 *6	03h
-----------------------	-----------------	----------	----------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2,*3,*4,*5,*6)

Hexadecimal Character	AUTO			NTSC			NTSC4.43			PAL			
	41h A	55h U	54h T	4Eh N	54h T	53h S	4Eh N	34h 4	34h 4	50h P	41h A	4Ch L	
PAL-M						PAL-N						SECAM	
Hexadecimal Character	50h P	41h A	4Dh M	50h P	41h A	4Eh N	53h S	45h E	43h C				

■ Note:

- This command is acceptable only when the input is VIDEO or S-VIDEO. In other cases, ER401 is returned.

2.73. Query RGB/YPrPb

Hexadecimal Character	02h Q	51h R	52h F	46h 03h
-----------------------	----------	----------	----------	------------

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h *1 *2	03h
-----------------------	-----------------	-----

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

■Parameters (*1,*2)

	RGB	YPbPr
Hexadecimal	30h	31h
Character	0	1

2.74. Query KEYSTONE

Hexadecimal	02h	51h	4Bh	53h	03h
Character	Q	K	S		

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

■Parameters (*1,*2,*3,*4,*5,*6)

	-60			-59			-58		
Hexadecimal	2Dh	36h	30h	2Dh	35h	39h	2Dh	35h	38h
Character	—	6	0	—	5	9	—	5	8
	58			59			60		
Hexadecimal	30h	35h	38h	30h	35h	39h	30h	36h	30h
Character	0	5	8	0	5	9	0	6	0

2.75. Query SHIFT H

Hexadecimal	02h	51h	48h	50h	03h
Character	Q	K	H	P	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	×	○	○

■Parameters (*1,*2,*3,*4,*5,*6,*7,*8)

	0				1			
Hexadecimal	30h	31h						
Character	0	0	0	0	0	0	0	1
	319							
Hexadecimal	30h	33h	31h	39h	30h	33h	32h	30h
Character	0	3	1	9	0	3	2	0

■Note:

- This command is acceptable only when the input is COMPUTER.. In other cases, ER401 is returned.
- The parameter differs according to the Input signals.

2.76. Query SHIFT V

Hexadecimal	02h	51h	56h	50h	03h
Character	Q	V	P		

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	×	○	○

■Parameters (*1,*2,*3,*4,*5,*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	36								38
Hexadecimal	30h	33h	36h	30h	33h	37h	30h	33h	38h
Character	0	3	6	0	3	7	0	3	8

■Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.

- The parameter differs according to the Input signals.

2.77. Query DOT CLOCK

Hexadecimal	02h	51h	44h	43h	03h
Character	Q	D	C		

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	x	○	○

■Parameters (*1,*2,*3,*4,*5,*6,*7,*8)

	1190				1189			
Hexadecimal	31h	31h	39h	30h	31h	31h	38h	39h
Character	1	1	9	0	1	1	8	9
	2894				2895			
Hexadecimal	32h	38h	39h	30h	32h	38h	39h	35h
Character	2	8	9	4	2	8	9	5

■Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.
- The parameter differs according to the Input signals.

2.78. Query FINE SYNC

Hexadecimal	02h	51h	43h	50h	03h
Character	Q	C	C	P	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	x	○	○

■Parameters (*1,*2,*3,*4,*5,*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	29				30			31	
Hexadecimal	30h	32h	39h	30h	33h	30h	30h	33h	31h
Character	0	2	9	0	3	0	0	3	1

■Note:

- This command is acceptable only when the input is COMPUTER1. In other cases, ER401 is returned.

2.79. Query SCREEN

Hexadecimal	02h	51h	53h	31h	03h
Character	Q	S	S	1	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character		*2	*4	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (*1,*2,*3,*4)

	NORMAL		WIDE		TRUE		FULL		ZOOM	
Hexadecimal	30h	31h	30h	32h	30h	35h	30h	36h	34h	30h
Character	0	1	0	2	0	5	0	6	4	0
	PITTARI-WIDE				COSTOM					
Hexadecimal	36h	30h	35h	30h						
Character	6	0	5	0						

*PITTARI-WIDE is only available for model VW435N series.

2.80. Query LANGUAGE

Hexadecimal	02h	51h	4Ch	47h	03h
Character	Q	L	G		

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (*1,*2,*3,*4,*5,*6)

	English			German			French		
Hexadecimal	45h	4Eh	47h	44h	45h	55h	46h	52h	41h
Character	E	N	G	D	E	U	F	R	A
	Spanish			Italian			Japanese		
Hexadecimal	45h	53h	50h	49h	54h	4Ch	4Ah	50h	4Eh
Character	E	S	P	I	T	L	J	P	N
	Chinese			Russian			Korean		
Hexadecimal	43h	48h	49h	52h	55h	53h	4Bh	4Fh	52h
Character	C	H	I	R	U	S	K	O	R
	Portuguese			Swedish			Norwegian		
Hexadecimal	50h	4Fh	52h	53h	56h	45h	4Eh	4Fh	52h
Character	P	O	R	S	V	E	N	O	R
	Danish			Polish			Czech		
Hexadecimal	44h	41h	4Eh	50h	4Fh	4Ch	43h	45h	53h
Character	D	A	N	P	O	L	C	E	S
	Hungarian			Thai			Holland		
Hexadecimal	4Dh	41h	47h	54h	48h	41h	4Eh	4Ch	44h
Character	M	A	G	T	H	A	N	L	D
	Finland			Romanian			Turkish		
Hexadecimal	46h	49h	4Eh	52h	55h	4Dh	54h	55h	52h
Character	F	I	N	R	U	M	T	U	R
	Arabic			Kazakhstan			Vietnamese		
Hexadecimal	41h	52h	41h	4Bh	41h	5Ah	56h	49h	45h
Character	A	R	A	K	A	Z	V	I	E

2.81. Query HDMI SETUP

Hexadecimal	02h	51h	56h	58h	3Ah	48h	53h	4Ch	49h	30h	03h
Character		Q	Ｖ	X	:	H	S	L	I	0	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	48h	53h	4Ch	49h	30h	3Dh	2Bh
Character		H	S	L	I	0	=	+
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*2	*4	*6	*8	*10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (*1,*2,*3,*4,*5,*6,*7,*8,*9,*10)

	EXPAND				
Hexadecimal	30h	30h	30h	30h	30h
Character	0	0	0	0	0
	NORMAL				
Hexadecimal	30h	30h	30h	30h	31h
Character	0	0	0	0	1

2.82. Query CLOSED CAPTION SETTING

Hexadecimal	02h	51h	43h	43h	03h
Character		Q	Ｃ	Ｃ	

■Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	x	○	○

■Parameters (*1,*2)

	OFF	CC1	CC2	CC3	CC4
Hexadecimal	30h	31h	32h	33h	34h
Character	0	1	2	3	4

■Note:

- This command is effective only when the system is fixed with "NTSC" and the proper signals (NTSC Video or S-Video signal) are input.

2.83. Query ASPECT (Available only for model VW435N series)

Hexadecimal	02h	51h	53h	46h	03h
Character	Q	S	F		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character	*	2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2)

	16:10	16:9	4:3
Hexadecimal	30h	31h	32h
Character	0	1	2

2.84. Query LOGO

Hexadecimal	02h	51h	4Ch	4Fh	03h
Character	Q	L	O		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character	*	2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2)

	OFF	USER	DEFAULT
Hexadecimal	30h	31h	32h
Character	0	1	2

2.85. Query AUTO INPUT MODE SELECTION

Hexadecimal	02h	51h	53h	53h	03h
Character	Q	S	S		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character	*	2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2)

	ON1	ON2
Hexadecimal	30h	31h
Character	0	1

■ Note:

- This command is effectice only when the Signal Search selects "ON1" or "ON2". In other cases, ER401 is returned.

2.86. Query INPUT SEARCH

Hexadecimal	02h	51h	53h	52h	03h
Character	Q	S	R		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character	*	2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2)

	OFF	ON
Hexadecimal	30h	31h

Character	0	1
-----------	---	---

2.87. Query BACKGROUND

Hexadecimal	02h	51h	42h	43h	03h
Character	Q	B	C		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2)

	BLUE	BLACK	USER
Hexadecimal	30h	31h	32h
Character	0	1	2

2.88. Query DIRECT ON

Hexadecimal	02h	51h	50h	59h	03h
Character	Q	P	Y		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

2.89. Query INSTALLATION

Hexadecimal	02h	51h	53h	50h	03h
Character	Q	S	P		

■ Response (Callback)

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2)

	FRONT/DESK	REAR/DESK	FRONT / CEILING	REAR/CEILING
Hexadecimal	30h	31h	32h	33h
Character	0	1	2	3

2.90. Query FAN CONTROL

Hexadecimal	02h	51h	46h	4Dh	03h
Character	Q	F	M		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character		*2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2)

	OFF	ON
Hexadecimal	30h	31h
Character	0	1

2.91. Query LAMP POWER

Hexadecimal	02h	51h	4Ch	50h	03h
Character	Q	L	P		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	03h
Character	*	2	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2)

	ECO	NORMAL
Hexadecimal	30h	31h
Character	0	1

2.92. Query POWER MANAGEMENT

Hexadecimal	02h	51h	41h	46h	03h
Character	Q	A	F		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	03h
Character	*	2	4	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2,*3,*4)

Setting OFF and setting of 0-30 minutes is possible by a unit for 1 minute.

The table below shows examples of "OFF", "0 min" and "30min".

	OFF	1	30
Hexadecimal	30h	30h	30h
Character	0	0	0

Hexadecimal	31h	33h	33h
Character	1	3	3

2.93. Query STANDBY MODE

Hexadecimal	02h	51h	56h	58h	3Ah	53h	54h	4Dh	49h	30h	03h
Character	Q	V	X	:	S	T	M	I	0		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	53h	54h	4Dh	49h	33h	3Dh	2Bh
Character	S	T	M	I	3	=	+	
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*	4	6	8	10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	○	○	○	○

■ Parameters (*1,*2,*3,*4,*5,*6,*7,*8,*9,*10)

NORMAL				
Hexadecimal	30h	30h	30h	30h
Character	0	0	0	0
ECO				
Hexadecimal	30h	30h	30h	33h
Character	0	0	0	3

2.94. Query EMULATE MODE

Hexadecimal	02h	51h	56h	58h	3Ah	45h	4Dh	55h	49h	30h	03h
Character	Q	V	X	:	S	E	M	U	I	0	

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	45h	4Dh	55h	49h	30h	3Dh	2Bh
Character	E	M	U	I	0	=	+	
Hexadecimal	*1	*3	*5	*7	*9	03h		
Character	*	4	6	8	10			

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■ Parameters (*1,*2,*3,*4,*5,*6,*7,*8,*9,*10)

	DEFAULT				
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	31h 1
D3500					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	32h 2
D4000					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	33h 3
D/W5k series					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	34h 4
D/W/Z6k series					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	35h 5
L730					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	36h 6
L780					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	37h 7
L735					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	38h 8
L785					
Hexadecimal Character	30h 0	30h 0	30h 0	30h 0	39h 9
LB/W series					
Hexadecimal Character	30h 0	30h 0	30h 0	31h 1	30h 0
F/W series					
Hexadecimal Character	30h 0	30h 0	30h 0	31h 1	31h 1

2.95. Query VOLUME

Hexadecimal	02h	51h	41h	56h	03h
Character	Q	A	V		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	03h
Character		*2	*4	*6	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

■ Parameters (*1,*2,*3,*4,*5,*6)

	0			1			2		
Hexadecimal	30h	30h	30h	30h	30h	31h	30h	30h	32h
Character	0	0	0	0	0	1	0	0	2
	61			62			63		
Hexadecimal	30h	36h	31h	30h	36h	32h	30h	36h	33h
Character	0	6	1	0	6	2	0	6	3

2.96. Query RUNTIME - LAMP

Hexadecimal	02h	51h	24h	4Ch	03h
Character	Q	\$	L		

■ Response (Callback)

In the period when the command can be accepted

Hexadecimal	02h	*1	*3	*5	*7	03h
Character		*2	*4	*6	*8	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

■ Parameters (*1,*2,*3,*4,*5,*6)

	0 h				1 h			
Hexadecimal	30h	30h	30h	30h	30h	30h	30h	31h
Character	0	0	0	0	0	0	0	1
	9998 h				9999 h			

Hexadecimal	39h	39h	39h	38h	39h	39h	39h	39h
Character	9	9	9	8	9	9	9	9

■ Note:

- If the lamp runtime cannot be accessed, 0000 is returned.

2.97. Query LAMP STATUS

Hexadecimal	02h	51h	24h	53h	03h
Character	Q	\$	S		

■ Response (Callback)

Lamp OFF

Hexadecimal	02h	30h	03h
Character	0		

In turning ON

Hexadecimal	02h	31h	03h
Character		1	

Lamp ON

Hexadecimal	02h	32h	03h
Character		2	

In turning OFF

Hexadecimal	02h	33h	03h
Character		3	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

2.98. Query TEMP INFORMATION

Hexadecimal	02h	51h	54h	4Dh	3Ah	*1	03h
Character	Q	T	M	:	:	*2	

■ Parameters (*1,*2)

	Intake temp.	Exhaust temp.	Optical temp.
Hexadecimal	30h	31h	32h
Character	0	1	2

■ Response (Callback)

Example: 20°C (68°F)

Hexadecimal	02h	30h	30h	32h	30h	2Fh	30h	30h	36h	38h	03h
Character	0	0	0	2	0	/	0	0	6	8	

Example: -10°C (14°F)

Hexadecimal	02h	2Dh	30h	31h	30h	2Fh	30h	30h	31h	34h	03h
Character		-	0	1	0	/	0	0	1	4	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

2.99. Query SERIAL NUMBER

Hexadecimal	02h	51h	53h	4Eh	03h
Character	Q	S	N		

■ Response (Callback)

Example: 123456789

Hexadecimal	02h	31h	32h	33h	34h	35h	36h	37h	38h	39h	03h
Character	1	2	3	4	5	6	7	8	9		

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

2.100. Query MAC ADDRESS

Hexadecimal	02h	51h	4Dh	41h	03h
Character	Q	M	A		

■ Response (Callback)

Example: AB0102030405

Hexadecimal	02h	41h	42h	30h	31h	30h	32h	30h	33h	30h	34h	30h	35h	03h
Character	A	B	0	1	0	2	0	3	0	4	0	5		

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	×	○	○	○

2.101.Query RUNTIME - PROJECTOR

Hexadecimal Character	02h Q	51h V	56h X	58h :	3Ah R	52h T	54h T	4Dh M	49h I	30h 0	03h
--------------------------	----------	----------	----------	----------	----------	----------	----------	----------	----------	----------	-----

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h R	52h T	54h M	4Dh I	49h 0	30h =	03h +
Hexadecimal Character	*1 *2	*3 *4	*5 *6	*7 *8	*9 *10	03h	

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (*1,*2,*3,*4,*5,*6,*7,*8,*9,*10)

Example: 55 hours

Hexadecimal Character	30h 0	30h 0	30h 0	35h 5	35h 5
--------------------------	----------	----------	----------	----------	----------

2.102.Query LAMP SERIAL NUMBER

Hexadecimal Character	02h Q	51h V	56h X	58h :	3Ah L	4Ch S	53h N	4Eh S	53h N	30h S	03h 0
--------------------------	----------	----------	----------	----------	----------	----------	----------	----------	----------	----------	----------

■Response (Callback)

In the period when the command can be accepted

Hexadecimal Character	02h L	4Ch S	53h N	4Eh S	53h 0	30h =	03h +		
Hexadecimal Character	*1 *2	*3 *4	*5 *6	*7 *8	*9 *10	*11 *12	*13 *14	*15 *16	03h

Acceptability

SECURITY	STANDBY (NETWORK)	STANDBY (ECO)	NO SIGNAL	AV MUTE	FREEZE
○	○	x	○	○	○

■Parameters (*1~*16)

Example: 12345678

Hexadecimal Character	31h 1	32h 2	33h 3	34h 4	35h 5	36h 6	37h 7	38h 8
--------------------------	----------	----------	----------	----------	----------	----------	----------	----------